



Important Notes:

- ① Insert backset here $2\frac{1}{2}''$, $2\frac{3}{4}''$, $3\frac{3}{4}''$, $5''$, $6''$.
- ② ASA strike mounted $1\frac{7}{8}''$ ABOVE centerline of Lever/Knob.
- ③ Prep for #12 wood screws (lock and strike).
- ④ Through-bolting holes **ONLY** if required. See trim manufacturers' standard template for details.
 Accurate locks accommodate $1\frac{1}{2}''$ to $1\frac{11}{16}''$ center to centers and up to $\frac{1}{4}''$ dia. post.
 If there are any additional questions about through-bolting, please contact us.
- ⑤ Knob/Lever holes may vary from different trim manufacturers. Please refer to their templates to confirm dimensions.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) Please contact us for double lipped template if needed.
- c) See spec sheets for additional lock details.