



- $\triangle$  Insert backset here 2,  $2\frac{1}{2}$ " or  $2\frac{3}{4}$ "
- $\triangle$  Centerline of strike is  $\frac{9}{32}$ " lower then Centerline of front.
- Prep for #8 wood or 8-32 machine screws.
- Through-bolting holes **ONLY** if required. See trim manufacturers standard template for details. Accurate lock's accommodates  $1\frac{1}{2}$ " to  $1\frac{11}{16}$ " center to centers and up to  $\frac{1}{4}$ " dia. post.

IMPORTANT: Through-bolting holes only apply to 2  $\frac{1}{2}$ " and 2  $\frac{3}{4}$ " backset locks (there is no through-bolting on the 2" backset version)

A Knob, thumbturn and ER holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

## Additional Notes:

- a) Responsibility: Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See Spec.9839 for additional details.



Standard 9839 Privacy Lock All Backsets

T-ALH.9839