



Notes:

- ▲ Insert backset here 2, 2 $\frac{1}{2}$ " or 2 $\frac{3}{4}$ "
 - ▲ Centerline of strike and front are the same.
 - ▲ Prep for #8 wood or 8-32 machine screws.
 - ▲ Through-bolting holes **ONLY** if required. See trim manufacturers standard template for details
- Accurate lock's accommodates 1 $\frac{1}{2}$ " to 1 $\frac{11}{16}$ " center to centers and up to $\frac{1}{4}$ " dia. post.
- IMPORTANT: Through-bolting holes only apply to 2 $\frac{1}{2}$ " and 2 $\frac{3}{4}$ " backset locks (there is no through-bolting on the 2" backset version)**
- ▲ Knob / Lever holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See Spec.9824 for additional lock details.



Standard 9824 Interior Bit Key Lock
All Backsets

T-ALH.9824