



**ACCURATE**  
 LOCK & HARDWARE  
 AMERICAN CRAFTED SINCE 1972

- ▲ Prep for #8 wood or 8-32 machine screws
- ▲ Horizontal and vertical pacing of the flush pull is u to the end user. However, we do suggest to line up the backset with the other locks on your project, i.e. 2 $\frac{1}{2}$ ", 2 $\frac{3}{4}$ "

2002CPDP Quiet Pocket Door Lock  
 Vantage Collection

T-ALH.VT.2002CPDP-Q