



 \triangle ASA strike mounted $1\frac{7}{8}$ ABOVE centerline of Lever/Knob.

A Prep for #12 wood screws (lock and strike).

Through-bolting holes **ONLY** if required. See trim manufacturers' standard template for details. Accurate locks accomodate $1\frac{1}{2}$ " to $1\frac{11}{16}$ " center to centers and up to $\frac{1}{4}$ "dia. post. If there are any additional questions about through-bolting, please contact us.

Knob/Lever holes may vary from different trim manufacturers. Please refer to their templates to confirm dimensions.

Additional Notes:

- a) Responsibility: Door and frame manufacturers are responsible for providing adequate contruction or re-inforcement for proper intallation of hardware shown.
- b) Please contact us for double lipped template if needed.
- c) See spec sheets for additional lock details.

T-ALH.M9159E-ELR.WD