



Notes:

- ▲ Insert backset here $2\frac{1}{2}"$ or $2\frac{3}{4}"$
- ▲ Centerline of strike and front are the same.
- ▲ Prep for #8 wood or 8-32 machine screws.
- ▲ Through-bolting holes **ONLY** if required. See trim manufacturers standard template for details
- ▲ Accurate lock's accommodates $1\frac{1}{2}"$ to $1\frac{11}{16}"$ center to centers and up to $\frac{1}{4}"$ dia. post.
- ▲ Knob, thumbturn and ER holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See spec sheets for additional lock details.