



T-ALH.9100.LL
T-ALH.9100TL
T-ALH.9100TT
T-ALH.9000LL
T-ALH.9000TL
T-ALH.9000TT
T-ALH.8500.LL
T-ALH.8600.LL
T-ALH.8700.LL
T-ALH.8800.LL



Notes:

- Corresponding lock templates (see side bar)
- Prep for #12 wood or 12-24 machine screws

additional notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) **Strike Fits ANSI A115.1 Standards**
- c) If door silencers are used on the frame, locate center line of strike from the surface of the silencer
- d) Please contact us if a double lip strike is needed - for a proper template
- e) See catalog / spec sheets for additional lock details
- e) Universal cutout shown for depiction only; many functions will receive a "two hole" or "latch only" cut out

Standard ASA Strike with Dust Box

T-ALH.ASA.STK

