

Cleaners – Parts and Hands Cleaners

How to apply LOCTITE® 7850

Application

- Rub into dry hands until dirt or grease is dissolved
- Wipe hands dry or rinse with water
- Repeat procedure if necessary



How to apply LOCTITE® 7063

Application

- Treat surfaces to be cleaned by generously spraying with LOCTITE® 7063
- Wipe surface when still wet with a clean paper towel
- Repeat if necessary until contamination is removed
- Allow solvent to evaporate until surface is completely dry

Note:

LOCTITE® 7063 can cause stress cracks on sensitive substrates.



How to apply LOCTITE® 7200

Application

- Before applying protect painted surfaces as LOCTITE® 7200 may attack the paint
- Spray a heavy coat onto flange or surface. Wait 10 – 15 min for the gasket to soften (for silicone gaskets 30 min)
- Remove gasket with soft scraper and wipe flange clean
- Repeat procedure if necessary



How to apply LOCTITE® 7840

Application

- Dilute LOCTITE® 7840 with water
- Soak or spray parts and wipe or rinse clean

Hint:

Effectiveness can be enhanced by diluting with warm water

