



OLD ORCHARD LODGE

Prefinished Wood Paneling



Aqua Clear Finish

The Aqua Clear has a crystal clear appearance, with UV inhibitors to keep it clear, greatly enriches the natural beauty of wood.



Premium Raw Pine

Premium grade is a good appearance knotty grade used in the same applications as Finish where larger and more numerous characteristics are desired.



Aqua White Finish

The coating is pigmented to give the wood an amazing whitewash look, and features UV inhibitors to prevent fading.



Manufactured by



Scan the QR code
for additional
product information



Contact your Amerhart sales representative for additional information.

PANELING INSTALLATION GUIDELINES

Process:

Old Orchard Lodge paneling is milled from Eastern White Pine logs from the great state of Maine. Beyond the meticulous profiling in the planer stage, the next step is to apply a protective sealcoat to the backside of the plank. The Old Orchard Lodge face is then vacuum coat- applied with either a clear coat, or a pigmented coating tinted with color shades that reflect the richness & diverse beauty of real wood. This coating is an environmentally friendly product. It is a 100% solids solvent- based, emitting zero VOCs due to being UV- cured immediately upon application. The UV- curing process provides the durability to Old Orchard Lodge that allows you to enjoy its beauty for many years to come.

Proper installation and maintenance of this product is crucial in order to provide lasting beauty for years to come.

Preparation: Wood is a living material which reacts to changes of relative humidity. It absorbs and releases moisture before and after it is installed depending on variations in the environment. Therefore all drywall, painting and concrete work must be completed before delivery of your wood paneling. The paneling should be received into the same environment in which it will be utilized long term.

Conditioning: Humidity changes may cause paneling to expand and contract as it is a natural product. This is not considered a product defect therefore neither the manufacturer nor distributor can be held responsible.

The effects of humidity changes can be greatly reduced by allowing the wood to acclimate to temperature and humidity within the room prior to installation.

Open all bundles and lay panels flat with air space between each layer in the room in which they are to be installed for 7-10 days before installation. Application without this breathing time will likely result in undesirable excessive expansion and contraction at the joints.

Installation: Because this paneling is genuine wood, each piece will vary in grain and color. Prior to installation, arrange boards in the best sequence for the most pleasing effect, and install accordingly.



- DO NOT nail through overlapping pieces.
- Vertical or horizontal applications.
- Tongue edge up in horizontal application.
- Using one casing nail per bearing to blind nail.
- Must penetrate 1-1/2" into solid wood base.
- Hide the nail heads with the next overlapping piece.