

COMPOSITE SOAP DISH

Clarion Bathware's Composite Surface Mounted Soap Dishes can be installed in one of two ways.

Method #1: Fasteners

If there is access to the backside of the shower unit; using fasteners is the optimal way to install the soap dish.

1. Determine the desired location of the soap dish. Mark a level line for the top edge, and a plumb line for one side.
2. Using the supplied template and aligning it with the level and plumb lines, mark and drill two (2) 1/4" holes to accept the mounting studs.
3. Clean both the backside of the soap dish and the areas where it will mount with solvent (rubbing alcohol, acetone, etc.) and a clean rag or paper towel.
4. Apply a 1/8" bead of silicone caulking on the back of the soap dish around the perimeter.
5. Slide the studs through the holes and press firmly to seat the soap dish into place.
6. Install and tighten the nuts onto the studs. Use caution not to over tighten.
7. Clean and silicone that may have squeezed out from behind the soap dish.

Method #2: VHB (Very High Bond) Tape Bonding

If there is no access to the backside of the shower unit; this method must be used.

1. Determine the desired location of the soap dish. Mark a level line for the top edge, and a plumb line for one side.
2. Using masking tape mask off the perimeter of the soap dish, so that you will not scratch the area not covered by the soap dish when sanding.
3. Using coarse sandpaper, sand the area on the shower where the soap dish will mount, use care to sand only the area that will be covered by the soap dish.
4. Clean the dust off of the sanded area. You may use rubbing alcohol on a **clean** paper towel to clean the sanded area.
 - a. On the backside of the soap dish there are strips of VHB tape, peel the backer off of the tape.
5. Place the soap dish against the shower wall and hold firmly in place using hand pressure.
6. After the soap dish is placed remove any masking tape and place a small bead of silicone caulking around the perimeter of the soap dish.
7. Please allow the silicone caulking to cure before use.

