



MAGNETIC PILLOW INSTALLATION INSTRUCTIONS

- 1. Remove the two magnets from the back of the pillow.**
Note: that there are 2 magnets on each side. Only the outer magnet should be removed.
- 2. Position the pillow into the desired position.**
- 3. Place the magnets onto the back side. The magnets will position themselves inline with the pillow magnets.**
- 4. Make final adjustments to pillow position**
- 5. Using 100% silicone or construction adhesive apply liberal amount in a continuous bead around the perimeter of the magnet.**
- 6. Leave pillow in place until the adhesive cures.**
- 7. Enjoy!**

JOB SITE INSTALLATION OF OWNER SUPPLIED ACCESSORIES

Job-site installation of third party supplied accessories or reinforcement is entirely at the risk and full responsibility of the owner. Any damage to Clarion Bathware units or the property during or after accessory installation, or any injuries due to improper installation remain the sole responsibility of said owner and cannot be attributed to Clarion Bathware, Inc.

CLARION BATHWARE PRODUCTS ARE CERTIFIED TO MEET CSA B45.5/IAPMO Z124 STANDARD. FOR DETAILS, PLEASE REFER TO ICC-ES PMG CERTIFICATION PROGRAM.



44 Amsler Avenue
Shipperville, PA 16254
(814) 226-5374 (800) 576-9228
Fax: (814) 226-0730 www.clarionbathware.com