

FIBERGLASS

Repair Kit Instructions

Kit Items:

- White gel coat
- Catalyst
- Mixing Cup
- Mixing Stick

1. Mix Thoroughly:

- a. 200 grams of white gel coat
- b. 3 grams clear Catalyst

2. Apply mix to the repair area and let sit for at least **10 min** or until cured completely (*apply thick as this will be sanded down*).
3. Grind with **100 grit** sandpaper. Then **600 grit** sandpaper until blended in.
4. Use wool buffer on area so that repair blends in.

Mixes can also be made smaller or larger as long as you keep it to a 1.5 percent catalyst ratio.

*****NOTE – do not over add Catalyst as this is very flammable.*****

