

Bezeichnung
Description

Schieferreparaturhaken 411®
Slate repair hook 411®

Anwendungsbereich
Scope of Application

Windsogsicherung von kleinformatigen Deckwerkstoffen.
Securing small format roof and facade coverings against wind uplift.

Technische Daten
Technical Data

Verpackungseinheit	100 Stück
Material	Kupfer / Edelstahl 1.4301 (schwarz u. blank)
Packaging unit	100 pcs.
Material	Copper / stainless steel 1.4301 (black and uncoated)

Montage
Installation

1. Defekte Schieferplatte entfernen.
2. Reparaturhaken auf der Fuge bzw. Unterkonstruktion so befestigen,
3. dass der Haken unterhalb der Gebindelinie umgeknickt werden kann.
4. Schieferplatte einschieben und Haken umbiegen, ggf. kürzen.
Die aktuellen Vorschriften für Dacheindeckungen und Herstellervorschriften sind bei der Montage zu beachten.

1. Remove defective slate plate.
2. Fix repair hook in the gap or subconstruction
3. beneath dash line for ease of bending.
4. Insert slate panel and bend hook, or shorten if necessary.
Please take note of the current roofing and manufacturer regulations.

Hersteller
Manufacturer

Friedrich Ossenberg-Schule GmbH + Co KG
Amerikastraße 2
58675 Hemer
GERMANY
Tel. +49 (0) 2372. 558. 99. 0
Fax +49 (0) 2372. 558. 99. 99 90
info@fos.de
www.fos.de

a	b	c	Code
120	3	35	411001
140	3	35	411002
160	3	35	411003

