


Quick Base Canopy Connector Compact 3 Tall



12 + 1x
T-Pegs




2x
Pole Thick



1x
Pole Thin

A


Canopy



A | 3-14

B

Canopy + Quick Base




B | 15-24


1

Instructions



A

Canopy







3 Add 2x Pole Thick




4

Add 1x Pole Thin





5



A | 7



6

Adjust height




7


Adjust height




8 Spread the canopy forward





1 Deconstruction



Remove









1

Instructions


B

Canopy + Quick Base






3 Add 1x Quick Base





4





5

Adjust height



6

Adjust height



1 Deconstruction

