

# Transcend™

## Highback Organizer

### Tools Required

- Screw Gun
- 7/32" Drill Bit
- #2 Phillips Head Bit

### Installation

1. The highback organizer sets on top of a worksurface. It can be attached to the worksurface using the double faced tape provided.
2. Attach double faced tape to the bottom of the highback organizer end panels. Position highback unit flush to back and side edges of the worksurface on unit without rim.  
**Note:** Double faced tape will create a strong bond. Make sure highback unit is positioned in desired location prior to final attachment. (Figure A).

Figure A

