

FRAME STARTER SPACER

Tools Required

- Drill driver
- Tape measure
- Level

Hardware Required

- Fastener (not included)

Installation

1. Determine Frame mounting location using tape measure.
2. Install spacer under Work|Able Lower Traxx at 2 high location, leveling with level. Using 2 fasteners at top and bottom of space in pre-drilled holes. Use wall anchors if needed.

Figure A

