
Assembly Instruction

Note: This assembly instruction will cover all configurations of the Alloy fixed height single sided beams.

From the bottom of the beam align the two inside v grooves with the four holes in the flat mounting brackets as shown in **Figure A**. Using the four provided self-drilling screws secure the beam to the brackets. Verify the beam is and brackets as aligned as shown below. It is recommended to use a clamp and pads when fastening the beam to help prevent misalignment.

Figure A:



Alloy

Fixed Single Beam

Package Contents

Hardware	Qty
#8 x 1 Wood Screw	16
Self Driving Screw	4

Tools Required

Screw Driver #2 Phillips Driver #3 Phillips Driver



Furniture with Personality*

Telephone 800.482.1717 Fax 812.482.8800 www.NationalOfficeFurniture.com

Part # 3051035 Rev, -


Printed in U.S.A © 2014 Kimball International, Inc.

Assembly Instruction

2

Align the beam assembly to the underside of the worksurface. Use the 16 provided wood screws to secure the assembly as shown in **Figure B**. Attach the table frame to the worksurface.

Figure B:



Alloy

Fixed Single Beam



Furniture with Personality*

Telephone 800.482.1717 Fax 812.482.8800 www.NationalOfficeFurniture.com

Part # 3051035 Rev, -

Printed in U.S.A © 2014 Kimball International, Inc.