Kolo 2 Add-On Carton plan + components

HEADS UP

- · Use this document to verify carton contents
- Kolo 4 or Kolo 6 assembly instructions are provided by your dispatcher and/or Kimball Project Manager


Kimball International

1600 Royal Street Jasper, IN 47546

CUSTOMER SERVICE (800) 482-1717 Lorem ipsum

©2024 Kimball International, Inc.

v24



Kolo 2 Add-On

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:

Read all instructions before using this Pod.

DANGER

To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning or servicing.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
- 2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
- 4. Keep the cord away from heated surfaces.
- 5. Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- 6. Never drop or insert any object into any opening.
- 7. Do not use outdoors.
- 8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 9. To disconnect, turn all controls to the off position, then remove plug from outlet.
- 10. Commercial use only and dry location use only.
- 11. Max load 9A for all receptacles.
- 12. Mount only approved work surfaces and secondary surfaces in accordance with instructions.
- 13. Risk of Injury to Persons Do not use pod walls to mount video equipment such as televisions or computer monitors without Manufacturing approved solution.
- 14. Smoke developed index over 450.

- 15. Contact your building manager or city fire Marshall before integrating this Pod into your buildings fire suppression system.
- 16. When not in use for extended periods of time we recommend disconnecting the power cord.
- 17. Not more than 2pcs room accessory model PPK2A-B22 for room model PPk2-B22

SAVE THESE INSTRUCTIONS

Kolo Series

Model number: Accessory Model # PPK2A-B22

For Room Model # PPK2-B22

Electrical Input: 120 VAC, 10A Max, 60 Hz



PAGE i


Kolo 2 Add-On INSTRUCTIONS FOR USE & MAINTENANCE

Cleaning and Care


- · Dust as needed with a damp cloth. Periodically clear accumulated dust from the fans and fan grills
- · Use only cleaners recommended for glass (non-ammonia) with a soft cloth
- · Vacuum interior floor and walls as needed
- · Spot clean floor, walls, and stool upholstery as needed using upholstery cleaners for polyester material
- · Use warm, soapy water to clean the work surface

How to Reposition + Level

- · Use an allen wrench to disengage the glides
- · Roll the Pod to it's desired location
- · Adjust each of the 4 glides, leveling the Pod so that the seams and shadow lines are square



Kolo 2 Add-On CARTON PLAN



Kolo 2 Add-On HARDWARE + SCREWS

| | [blank] | A 8 | M8x60mm - Allen | |
|------------|-----------------|------------|-----------------|--|
| A 2 | M8x50 - Hex | QTY. x1 | A/C Outlet | |
| A 4 | Spring Washer | | | |
| A 6 | Alignment Pin | | · | |
| A 7 | M8x35mm - Allen | | | |

Kolo 2 Add-On


COMPONENTS

| C ₂ | Floor | G ₃ | Ceiling Corners | |
|----------------|--|----------------|---------------------------|--|
| QTY. x1 | | QTY. x2 | | |
| D 3 | Floor Corner | P | Center + Side Floor Tiles | |
| QTY. x1 | A state at the state of the sta | QTY. x3 | P1 P2 P1 | |
| D ₄ | Floor Corner | Q | Finishing Panels | |
| QTY. x1 | | QTY. x4 | Q1 Q2 Q4 | |
| E 3 | Side Wall | | | |
| QTY. x2 | | | | |
| F ₂ | Ceiling | | | |
| QTY. x1 | | | | |


- · Remove the two screws connecting the floor corners and floor
- · Remove foam and discard
- · Remove three screws from the A/C Outlet and use them to install the AC outlet into floor corner **D3**, facing the correct orientation

HEADS UP!


• Ensure that the A/C outlet cords are coming out on the side of the floor corner with the internal nut




- · Orient the floor corners so the internal nut faces the Kolo 2 base unit
- · Install four alignment pins
- · Screw the floor corners and floor together using four screw
- · For stability during assembly, engage the glides



- · Removecover plate from A/C outlet and set aside to reinstall later
- Assemble the walls



- · Remove the two screws connecting the ceiling corners and ceiling
- · Install four alignment pins
- · Screw the ceiling corners and ceiling together using four screws
- · Orient the ceiling corners so the internal nuts face the Kolo 2 base unit



· Install the ceiling

