

Getting Started With

Rad-Control Irradiation Tags



- 1 Wipe off any condensation from the surface of the blood bag.

- 2 Apply the tag to a clean, dry area.
Tip: Keep part of the tag on the blood bag label for better adhesion.



- 3 Press down firmly to effectively adhere the tag.



Helpful Tips

- Refrain from bending the tag, particularly around the indicator window.
- Avoid exposure to direct sunlight and UV light.
- Store away from sources of radiation.