# Pro Vision Uno/Duo Hardwire



## Install Guide

#### What's included

O Dash camera

(2) 3M adhesive tape

Power adapter cable

Allen key

3-wire cable for hardwiring

Lock screw

Mounting bracket

Not included, but required: Multimeter

#### Not included, optional for installation:

 Adhesive clips to neatly run cabling across windshield/vehicle  Interior soldering iron or crimp connectors Electrical tape

## Prepare your materials

Ensure you have all the necessary materials ready.



Note: Installation is not recommended in temperatures below freezing. If unavoidable, use hot air to slightly warm the location that you are mounting the adhesive tape to.

## **Mounting location**

- Make sure the camera has a clear view of the road and doesn't obstruct your view while driving.
- Clean and dry the area for installation, ensuring no dust or oily residue is present.
- · Measure and mark the center of the windshield.
- Measure horizontally to find the center of the windshield and vertically to find the best positioning for the front-facing camera.

# Pro Vision Uno/Duo Hardwire



### Install Guide

### Mount the dash cam

- Peel off one side of the 3M sticker film and adhere it to the mount.
  Attach the mounting bracket to the dash cam with the lock screw.
- Peel off the opposite side of the 3M sticker film and adhere the mount to the marked location on your windshield. Ensure it is securely attached.



#### Power on the vehicle

#### Body of camera LED will light up as follows:

- The power LED will illuminate and be constant (no flashing).
- The NET GPS and ALARM LED will flash at different intervals.
- The device will start and try to get network connectivity. Next, the LED will start to flash.
- Once the device receives network connectivity, both the NET and GPS LED will be constant.
- The dash camera is now fully powered on and ready.

# Connect power cables



IMPORTANT: VEHICLE MUST BE POWERED OFF DURING THIS STEP. ALWAYS CONNECT THE CABLE TO THE DASH CAM FIRST, TO AVOID DAMAGE TO THE DEVICE.

- Connect the 3-wire cable and device power box cable together. Plug into the camera.
- Run the device cable to headliner and neatly tuck cable under headliner. Continue running the cable to the driver side A pillar, down toward the vehicle engine cabin, then toward the vehicle battery.

#### Connect 3-wire cable to vehicle battery as follows:

- Connect red wire to Power Positive + on vehicle battery.
- 2. Connect orange wire to Ignition.
- Connect black wire to Power Negative on vehicle battery.

