

INSTALLATION: Insert machine screws provided through both holes in the recessed item and fasten loosely into recessed wall clamp. Install only the clamp portion into the cut hole in wall by angling the corners first upward behind the hole then downward. Tighten screws

while positioning recess item and clamp until flush with wall.

