

# HTOVLAPR CANE APRON INSTALLATION

1. REMOVE 5 SCREWS AND BOTTOM COVER PLATE.
2. ATTACH ITEM 1 (CANE APRON) WITH FOUR SCREWS PREVIOUSLY REMOVED.
3. BOTTOM COVER AND REMAINING SCREW CAN BE DISCARDED.

