

INSTALLATION INSTRUCTIONS

TOOLS NEEDED:



DO NOT USE:



For toilet base with four holes, screws are used in the front two holes.

1. Line up toilet bowl base. Through front two holes on base, carefully drill 3/16" pilot/starter holes in floor.
2. Insert screws. Place brass washers, then closed-end nuts over screws.
3. Tighten nuts carefully with wrench. **DO NOT OVERTIGHTEN** or bowl may crack.

For toilet base with four holes, toilet bowl bolts are used in the back two holes to secure bowl to floor flange (use Fluidmaster Model 7111). If new bolt caps are needed, use Fluidmaster Model 7115 or 7116.

