

0816422	
D041868	
SS	
22	
Pro/E	
P0041868	
MDL: 001-03	DWG: 002-00
REV	CHANGES
△	ECN7471
△	10-12-10 MH
△	ECN8098
△	07-23-12 MGK

## INSTRUCTIONS FOR MOUNTING SS3002, SS3102 & SS3802 LAVATORY

1. Use straightedge rule to make sure countertop is perfectly flat in both length and width.
2. Mark centerlines for location of lavatory in slab or countertop.
- △ 3. Cut out template at solid line and orient centermarks with centerlines on countertop.
- △ 4. Trace outline onto countertop and cut opening.
5. Assemble faucet and drain in lavatory.
6. After opening is cut, apply two continuous beads of adhesive between the opening and the outside line. Spread slightly with a flat tool.
- △ 7. Set the lavatory in proper position.
8. Press down firmly on rim of lavatory to distribute adhesive.
9. Remove excess adhesive with a dry cloth.
10. If necessary, work in additional adhesive around outer rim edge immediately.
11. Dampen a cloth with rubbing alcohol, and wipe fixture and countertop clean as soon as lavatory has been placed.

BROKEN LINE REPRESENTS LAVATORY RIM WHEN SET

△ CUT COUNTERTOP ALONG SOLID LINE

### CHARACTERISTIC CONTROL

▼ CRITICAL DIMENSION	- NO DEVIATION OUTSIDE OF TOLERANCE ZONE
○ INSPECTION DIMENSION	- MUST BE CHECKED ON EACH LOT
⬢ TOOLING DIMENSION	- TOOLING REQUIREMENT

UNLESS OTHERWISE SPECIFIED DIMENSIONS IN INCHES (MILLIMETERS) X.X ±.06 (1.5) X.XX ±.01 (0.25) X.XXX ±.005 (0.12) © .010 (0.25) FIM ≤ ±2°	TEMPLATE - COUNTERTOP HOLE (SS-3002, SS-3102, SS-3802 SINKS)		SCALE: 1:1	PART NUMBER SS 22
	THE INFORMATION CONTAINED ON THIS PRINT IS CONFIDENTIAL AND MAY NOT BE REPRODUCED WITHOUT THE WRITTEN PERMISSION OF SLOAN VALVE COMPANY		DATE MODIFIED 07/23/2012	DRAWING NUMBER D041868
FRANKLIN PARK, ILL.	CHK'D BY MS	APPR BY PJJ	DATE 09-29-10	MATERIAL MASTER NUMBER 0816422