

## LAVATORY DRAIN INSTALLATION INSTRUCTIONS

MODEL No's: 320, 3201, 3202, 3203

### Installation instructions:

1. Assemble Stopper, O-ring, Post & Flange. Secure with Screw.
2. Thread flange Nut on Tailpipe. Place washers on Tailpipe and insert through drain hole from underside of sink basin.
3. Thread Tailpipe to Flange/Stopper assemble. Note: Recommended to add a clear silicone adhesive between Flange and Sink basin to seal.
4. Tailpipe to be received by existing P-Trap.

