

Wax Closet Gaskets

Specifications:

Furnish and install AB&A's Wax Closet Gasket which is 100% pure wax gasket for setting all floor outlet toilet bowls. The gasket will form a water tight, gas tight and odor tight seal. Fits 3" and 4" waste lines. Available with plastic horn which extends the discharge opening to create a more positive seal and assure proper bowl alignment.

Certifications:

Meets federal specifications A-A-3110

Instructions:

Install at temperatures of 70°F or above to ensure proper distribution of wax.

- 1. Remove the existing wax closet gasket using a putty knife. Scrape the residual wax from the closet flange, floor, and underside of the toilet. Wearing gloves is recommended.
- 2. Center the AB&A wax closet gasket on the closet flange with the rounded side up.
- Carefully lift the bowl over the closet flange, align with the flange bolts and set it in place. Twist the bowl slightly to spread the wax and use your body weight to seat the bowl on the floor. Do not rock the toilet.
- 4. Secure the nuts on the flange bolts. Be careful to not over-tighten.
- 5. Place bolt cap over bolts, reconnect the water supply connector nut to the fill valve under the tank.





500 Distribution Parkway, Collierville, TN 38017 = Phone: 800-888-8312 = Fax: 901-853-5008 = www.ipscorp.com





