

Structural Attachments – Beam



Structural Attachments – Beam

-
- A close-up photograph of a silver-colored metal clamp, likely a C-clamp, attached to a wooden beam. The clamp is secured with a bolt and nut. The background is dark and out of focus.



Set screw must be tightened and torqued onto the sloped side of the I-beam, channel, or angle iron flange. Recognizing that torque wrenches are generally not used or available on many job sites, the setscrew should be tightened so it contacts the I-beam and then an additional 1/4 to 1/2 turn added.

-



Setscrew must be tightened and torqued onto the sloped side of the I-beam. Recognizing that torque wrenches are generally not used or available on many job sites, the setscrew should be tightened so it contacts the I-beam and then an additional 1/4 to 1/2 turn added.