

OutSet Plus⁺

Rigid Core Luxury Vinyl

100% Waterproof

Multi-layer Quartz Enhanced Urethane Coating

Giving floor its extra resistance to heavy foot traffic, scuffs and micro-scratches

Deep Structured Decorative Layer

Providing the look & feel of premium hardwood

Rigid Limestone-based Core

- Extra stable & rigid
- 100% waterproof
- Free of Ortho-Phthalates

◆ 100% WATERPROOF

◆ ULTRA STABLE Resistant to Heat and Sunlight

◆ HIGH DENSITY RIGID CORE No Telegraphing of Small Under Floor Imperfections

◆ PERFECT FOR EVERY ROOM Including Kitchens, Bathrooms, Sunrooms

◆ EASY-TO-INSTALL No Glue, No Mess, No Additional Tools Needed



Color Name	Size"	Thickness(mm)	Pcs	SF / CTN	SKU
Silver Lining	7 X 48.62	3.0	15	35.49	5524997

Product Dimensions:

- Thickness: 3mm
- Width: 7" (178mm)
- Length: 48.62" (1235mm)

Product Specifications:

- 6mil (0.15mm) wear layer
- 15 planks / 35.49sq.ft per carton
- Can install 60 lineal ft without any transition moldings!

Acclimation:

No acclimation needed except if boxes were exposed to extreme temperatures (under 50 °F (10 °C) or over 100 °F (38 °C)) within the 12 hours before the installation, acclimation is required. In this case, keep the boards in room temperature for at least 12 hours in unopened package before you start the installation

Expansion:

1/4 (6mm) around perimeter of room

Joint Stagger:

Minimum of 12 inches (30cm)

Maintenance:

- Clean with a non-wax vinyl floor cleaner
- Not recommended to use oil soap, bleach or other abrasive cleaners
- Clip pet nails, use non-rubber backed rugs, use felt pads on furniture

Radiant in Floor Heat:

Only use embedded floor heating systems

Subfloor:

- Needs to be level within 3/16" (5mm) over a 10-foot (3m) span
- Concrete (CEM) moisture level should be a maximum of 2.5%
- May be installed in any room or grade (except for sunrooms that have no heating or AC unit)

Tools Required:

Spacers, rubber mallet, ruler, pencil, tape measure, utility knife



Residential
Warranty



CFL CUSTOMER SERVICE LINE: 888-271-3859



PLEASE READ CAREFULLY

Thank you for purchasing our luxury vinyl product. We have included some helpful hints to insure that your luxury vinyl flooring is installed properly.

- **DO** leave an expansion gap of 1/4" (6 mm) around the perimeter of the room.
- **DO** work out of more than one carton at a time when installing the flooring planks. This will ensure a more natural look!
- **DO** make sure your subfloor is flat and level. Unlevel subfloors can cause the planks to become disengaged over time.
- **DO** use chair protectors and walk off mats to help prevent scratching. This is a high quality vinyl floor that if maintained, will last for years.
- **CAN** be installed over existing floors
 - Concrete: **DO NOT USE PLANKS AS A MOISTURE BARRIER.** Concrete subfloors must be fully cured and should have minimum 6 mil (0.15mm) poly-film as a moisture barrier between the concrete subfloor and the flooring.
 - Tile: Make sure to level out your tile floor. If clicks overlap a grout line it may compromise the integrity of the click system, fill up grouts wider than 1/4" (6 mm) with a leveling compound when installing over tiles
 - Wood: Be sure that wood floor is flat and stable. If noisy planks are present, fix them before installing the floor.
- **MAY** glue down product but be sure to use a waterproof, hard-setting acrylic adhesive.
- **DO NOT** install over subfloors with non-embedded radiant heat.
- **DO NOT** use a tapping block. These will break the locking mechanism with the planks.
- **DO NOT** install outside.