



Thank you for purchasing our luxury vinyl product.

We've included some helpful hints to ensure that your luxury vinyl flooring is installed properly.

- DO leave an expansion gap of ¼" around the perimeter of the room. Your flooring will expand and contract with temperature changes within the home as well as direct sunlight.
- DO work from 3-4 cartons at a time when installing the floor. It will ensure a more natural appearance in the floor.
- DO make sure your subfloor is clean, flat and level. You must fill in low spots (dips in subfloor) and flatten high spots (bumps in subfloor). Any subfloor that is not flat and/or level can cause the joints on the planks to break and the floor to separate over time. (NOTE: your floor must be level within 3/16" over a 10' radius.)
- DO use chair protectors, mats and rugs to help prevent scratching. This is a high quality vinyl floor that if maintained, will last for years. If not protected properly, as with other floor covering such as hardwood and laminate, it will scratch. Scratches may be caused by pets, furniture, rocks from shoes, and many other abrasive items.
- CAN be installed over most existing hard surface floors:
- Concrete: DO NOT USE THE PLANKS AS A MOISTURE BARRIER. Concrete subfloors must be fully cured and should have a 6mil (0.15mm) poly-film as a moisture barrier between the concrete
- subfloor and the floor.
- Tile: Make sure to fill up grouts wider than ¼" with a leveling compound. If the click overlaps with a grout line it may compromise the integrity of the click system.
- Wood: Be sure the wood floor is flat and stable, repair any loose or squeaking planks before installing the floor
- DO NOT install your flooring over subfloors with non-embedded electrical radiant heat
- DO NOT install outdoors or over carpet
- DO NOT install kitchen cabinets directly over your floor.

Shop online and get a Free Flooring Estimate at

www.homeoutlet.com

*See store for details