

TOP FIT

Repair Kit for the external repair of layflat delivery hoses

Quality made in Germany



Repair Box TOP FIT complete

consisting of:

2 pc. patch repair material, 10 x 15 cm, red – white

pair of scissors

brush

plastic bottle to be filled with acetone (not supplied)

Teflon folia

repair instruction

Note

Good repair results can be achieved for damage up to 5 mm hole diameter or 10 mm tear length.

In the case of Red coated hoses the “red” side of the patch repair material should be uppermost, and for White (uncoated) hoses the “white” side should be used.

Storage

We strongly recommend that large quantities of the patch repair material be stored in a deep freeze (-10° C to 15° C) in order to prolong its usable service life. However the repair material can be purchased as a stock item in small quantities for immediate use if long term storage is a problem.

Shelf Life

We make every effort to always provide fresh patch repair material and send by the quickest means of transport but on receipt we ask our customers to immediately store the material under the following conditions:

Deep freeze

-10°C to -15°C

Refrigerator

+15°C

Room temperature

+20°C

Long term storage

(Minimum 24 months)

Normal storage

(Minimum 12 months)

Immediate Workshop Use

(4-6 weeks)

Accessories



PARSCH

Schläuche • Armaturen

TOP FIT Repair Kit is especially
suitable for use with the Pronto P10
Vulcaniser



for further details please refer to the
leaflet PRONTO P10

Important Note:

**For successful repairs
always make sure that fresh
repair material is used.**

PARSCH

*Schläuche • Armaturen
GmbH & Co. KG*

Gildestraße 16

49477 Ibbenbüren/Germany

Telefon: +49 (0) 5451 9 29-0

Fax: +49 (0) 5451 92 92 92


www.parsch.de

info@parsch.de


Quality made by Parsch

TOP FIT

Repair instructions for the Pronto P10 vulcaniser using the TOP FIT Repair System



In case of Rubber Covered Hoses please refer to 1a und 2a



Repair instructions

With the TOP FIT repair kit you can repair Uncoated, Polyurethane Coated as well as Rubber Covered layflat Delivery Hoses (see notes 1a & 2a). This repair system does not require an internal patch repair as the external repair system provides all the strength necessary to put a damaged hose back into service.

1. Trim off torn threads around the damage to give clean, neat edges.
2. Cut a suitable size patch from the patch repair material allowing a 2 cm overlap of the damage in all directions.
3. Thoroughly clean the damaged area larger than the patch with acetone to remove all traces of oil & grease, etc.
4. Remove the protective film from both sides of the patch and round-off the corners.
5. Form a small rubber plug of the repair material and fill the hole to be repaired completely and apply acetone.
6. Apply a generous quantity of acetone to the surface of the underside of the patch until it becomes soft and tacky.
7. Press the patch firmly down on the damaged area.
8. Place the hose with the repaired area in the centre of the base plate (patch uppermost) of the PRONTO P10 vulcaniser and cover the patched area with the sheet of Teflon folia Release Material.
9. Press down the clamping lever of the vulcaniser to firmly hold the hose area to be repaired. Set the vulcaniser timer for **15 minutes**. The vulcaniser will switch off automatically when the curing process is finished.

Accessories



Important Note:

After the vulcanisation period of 15 minutes has finished please keep the hose under pressure until the heating unit has completely cooled down. After 24 hours the hose can be pressure tested with the working pressure according to the prevailing hose standard.

Repair instructions for Rubber Covered Hoses:

1a) For this type of hose first of all remove the external cover around the damage back to the textile reinforcement.



2a) The size of the repair patch should be 2 mm smaller than the removed external cover.



certified according to
DIN EN ISO 9001 : 2008
Quality Management System

Quality made by Parsch