



Neutral for Latching relay should be taken from the same panelboard since there is Residual current breaker in panelbards