



INSTALLATION TIPS FOR NUVELLE PARADISO FLOORING

In addition to the installation guidelines for Nuvelle's Paradiso flooring, please utilize the information below to help ensure the installation is both easy and successful:

1. Nuvelle's Paradiso product is designed to lock together easily with very little force needed.
 - a. When folding a plank down, place the "tongue" end (the plank that is being folded down) into the "groove" end of the installed plank.
 - b. Make sure the plank ends are aligned squarely with one another.
 - c. Using your thumb, apply firm pressure at points all along the seam - this step securely engages the locking mechanism and you may feel or even hear the joint engage.
2. Check the seam for ledging (one plank slightly higher than the other) by rubbing your fingers/hand gently across the seam.
 - a. Moderate ledging (*uneven plank heights at the seam*) can still be present at this point - if so, this means that the locking profile is not fully seated and further efforts need to be made to fully engage the locking system.
 - b. At this point, put VERY firm pressure on the part(s) of the seam where ledging exists.
 - c. It can be helpful to place the head of a rubber mallet directly onto the seam where ledging exists and apply downward pressure by pressing onto the mallet head.
 - d. After doing this, check for ledging by rubbing your fingers/hand gently across the seam.
3. If ledging is still present, firmly TAP (not a full-fledged STRIKE) all along the seam to fully-engage the lock.
 - a. IMPORTANT: When TAPPING along the seam, DO NOT tap directly onto the seam (photo on left) as doing so can and will permanently damage the locking system.
 - b. Instead, the mallet head should strike about 1/2 inch to 1 inch away from the seam ON THE TONGUE SIDE (photo on right) – to prevent damage, DO NOT strike or tap DIRECTLY ON THE SEAM.



Incorrect (on the seam)



Correct (1/2" to 1" away from seam)

CONSEJOS DE INSTALACION PARA DE PARADISO NUVELLE

Además de las pautas de instalación para los pisos de Paradiso de Nuvelle, utilice la siguiente información para garantizar que la instalación sea fácil y exitosa:

1. Los producto Paradiso de Nuvelle están diseñados para unirse fácilmente con muy poca fuerza.
 - a. Al doblar una tabla hacia abajo, coloque el extremo de la “lengüeta” (la tabla que se está doblando hacia abajo) en el extremo de la “ranura” de la tabla instalada.
 - b. Asegúrese de que los extremos de las tablas estén alineados directamente entre sí.
 - c. Con el pulgar, aplique una presión firme en puntos a lo largo de la costura; este paso engancha de forma segura el mecanismo de bloqueo y es posible que sienta o incluso escuche cómo encaja la articulación.
2. Revise la costura en busca de salientes (una tabla ligeramente más alta que la otra) frotando suavemente la costura con los dedos o la mano.
 - a. En este punto todavía puede haber un saliente moderado (alturas desiguales de los tablones en la costura); si es así, esto significa que el perfil de bloqueo no está completamente asentado y se deben hacer más esfuerzos para enganchar completamente el sistema de bloqueo.
 - b. En este punto, ejerza una presión MUY firme en la(s) parte(s) de la costura donde existe el saliente.
 - c. Puede resultar útil colocar la cabeza de un mazo de goma directamente sobre la costura donde existe el saliente y aplicar presión hacia abajo presionando sobre la cabeza del mazo.
 - d. Después de hacer esto, verifique que no haya salientes frotando suavemente la costura con los dedos o la mano.
3. Si todavía hay salientes, golpee firmemente (no con un golpe completo) a lo largo de la costura para enganchar completamente el bloqueo.
 - a. **IMPORTANTE:** Al GOLPEAR a lo largo de la costura, NO golpee directamente sobre la costura (foto a la izquierda), ya que hacerlo puede dañar permanentemente el sistema de bloqueo.
 - b. En cambio, la cabeza del mazo debe golpear aproximadamente a 1/2 pulgada a 1 pulgada de la costura **EN EL LADO DE LA LENGUA** (foto a la derecha); para evitar daños, NO golpee ni golpee **DIRECTAMENTE EN LA COSTURA**.



Incorrecto (en la costura)



Correcto (de 1/2” a 1” de la costura)