



| ADDITIONAL SPINDLE SPACERS FOR FATBIKES | | | |
|---|---------------------------|--------------------------------|-----------------------------------|
| BB Shell Type | RF 30mm Spindle Length | Drive Side Spindle Spacers* | Non-Drive Side Spindle Spacers |
| PF30 - 100mm | 169.5mm (RF169) | 1 x 1.5mm | 1 x 1.5mm |
| | 189.5mm (RF189) | 1 x 11.5mm | 1 x 11.5mm |
| PF30 - 120mm | 189.5mm (RF189) | 1 x 1.5mm | 1 x 1.5mm |

*2.5mm spindle spacer supplied with PF30 BB remains on Drive side spindle on all PF30 setups in addition to fatbike spacers.

PLEASE CHECK RACEFACE.COM/SUPPORT FOR THE LATEST UPDATES









В30069-В