



491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: www.bds-suspension.com

E-mail: tech-bds@ridefox.com

Part#: 124000

Product: Transfer Case Drop Kits

Application: Jeep CJ

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Using a floor jack under the transfer case cross member, loosen and remove the six frame to cross member bolts and spacers.
2. Carefully lower floor jack so that the cross member is approximately 1 inch below the frame.
3. Insert 3 spacers per side, install the new hardware and tighten to 40-50 ft/lbs. Remove the floor jack.
4. Periodically inspect assembly for tightness.