


Front Differential Drop

Toyota Tundra | 2007-2016

Part #: 128006

Rev. 100616



491 W. Garfield Ave., Coldwater, MI 49036 • Phone: 517-279-2135

Web/live chat: www.bds-suspension.com • E-mail: tech-bds@sporttruckusainc.com

SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park vehicle on clean flat and level surface. Block the rear wheels for safety.
2. Remove the front lower skid plate (if equipped).
3. Support the front differential with a hydraulic jack.
4. Remove the 2 front bolts from the vehicle with 19mm wrenches.
5. Lower the differential with the hydraulic jack.
6. Install the provided spacers in the gap. Install original cup washer on the new 1/2" x 6" bolts. (Fig 1)
7. Install serrated edge flanged nut on top of the factory crossmember. Tighten to 65 ft-lbs.
8. Reinstall the factory skid plate (if equipped) with factory hardware to the crossmember under the radiator. Attach with (3) 8mm x 40mm bolts and 5/16" USS washers with (3) spacers to the differential mounting crossmember. Tighten to 25 ft-lbs.
9. Recheck hardware after 500 miles and at regularly scheduled maintenance intervals.

Box Kit		
Part #	Qty	Description
935	1	Bolt Pack - Differential Drop
	2	1/2"-13 x 6" bolt
	2	1/2"-13 serrated edge flanged nut
	3	8mm-1.25 x 40mm bolt
	3	5/16" USS washer
73	3	Skid Plate Spacers
01413	2	Diff Drop Spacers

FIGURE 1

