

Heavy-Duty Rear Sway Bar Link

Ford Super Duty F250 / F350 | 2017-2020

Part #: 123808

Rev. 111419



491 W. Garfield Ave., Coldwater, MI 49036 • Phone: 517-279-2135

Web: www.bds-suspension.com • E-mail: tech-bds@ridefox.com

SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Disconnect the sway bar links from frame and sway bar. Discard the sway bar links and hardware, they will not be reused. (Fig 1)

FIGURE 1



2. Lightly grease and install bushings and sleeves into the new sway bar links.
3. Install the sway bar links with new 12mm hardware from Bolt Pack 807 in the factory frame mount and sway bar.
4. Tighten 12mm hardware to 40 ft-lbs.
5. Check all fasteners after 500 miles.

123808- Sway Bar Links Box Kit

Part #	Qty	Description
911125	2	Sway Bar Links
SB58BK	4	Hourglass Bushing
62147	4	0.625 x 0.075 x 1.375 Sleeve
807	1	Bolt Pack
	4	12mm-1.75 x 60mm Bolt
	8	7/16" USS Washer
	4	12MM-1.75 Prevailing Torque Nut

TIME TO HAVE SOME FUN

Thank you for choosing BDS Suspension.

For questions, technical support and warranty issues relating to this BDS Suspension product, please contact your distributor/installer before contacting BDS Suspension directly.