



491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: www.bds-suspension.com

E-mail: tech-bds@ridefox.com

Part#: 124409

Rear Sway Bar Links

1999-2004 Jeep Grand Cherokee WJ

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Block the front wheels for safety.
2. Remove the OE rear sway bar links. Retain the upper mounting hardware, discard the lower hardware.
3. Lightly grease and install the provided bushings and sleeves in the new rear sway bar links (01473). Install the links to the frame with the original hardware. Attach the links to the sway bar with 3/8 x 2-1/2" bolts, nuts and 3/8" USS washers (BP #546). Torque hardware to 30 ft-lbs.
4. Check hardware after 500 miles.