



491 W. Garfield Ave., Coldwater, MI 49036  
Phone: 517-279-2135  
Web/live chat: [www.bds-suspension.com](http://www.bds-suspension.com)  
E-mail: [tech@bds-suspension.com](mailto:tech@bds-suspension.com)

Part#: **128309**

Product: **Rear Sway Bar Links**

Application: **Toyota FJ Cruiser**

---

**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

---

**SAFETY WARNING** BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

**INSTALLATION INSTRUCTIONS**

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the rear sway bar links, retain bushings / washers for later use.
3. Install new sway bar links with new lower hourglass shaped bushing and sleeve. Attach with 12mm x 60mm bolt with 7/16" USS (large outside diameter) washers, and nut (BP #518). Attach top of sway-bar link with O.E. bushings / washers and new 5/16" nylock nut. Tighten 5/16" nut until bushings begin to swell, torque 12mm hardware to 45 ft-lbs.

ⓘ Note: This accessory uses a common bolt pack with the main suspension lift kit. You will have extra fasteners when the installation is complete.

**PARTS LIST**

<b>Part #</b>	<b>Qty</b>	<b>Description</b>
518	1	Bolt Pack
01434	2	Rear Sway Bar Links
SB58RB	2	Sway Bar Link Bushing
62147	2	0.625 x 0.075 x 1.375 Sleeve