

## **SAFETY WARNING**

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

## INSTALLATION INSTRUCTIONS

- 1. Park vehicle on clean, flat, and level surface. Block the wheels for safety. It is best to install this kit with the vehicle on the ground.
- 2. Support the driveshaft and remove the two bolts that attach the carrier bearing to the cross member.
- 3. Lower the carrier bearing so that the drive shaft is in line through the carrier bearing. Install the spacers that get this spacing correct. Attach with new 10mm fully threaded bolts. A general starting place would be ¼" of carrier bearing drop for every 1" of additional lift in the rear. Tighten to 41 ft-lbs.
- 4. Test drive vehicle and ensure there is no vibration. Additional adjustment may be required.
- 5. Check hardware after 500 miles.

Box Kit		
Part #	Qty	Description
818	1	Bolt pack
01023	1	1/8" spacer
01024	2	1/4" spacer
01025	1	3/8" spacer
03889	1	1" spacer