


Differential Skid Plate Kit

Chevy HD 2500 | 2011-2016

Part #: 121251

Rev. 052616



491 W. Garfield Ave., Coldwater, MI 49036 • Phone: 517-279-2135

Web/live chat: www.bds-suspension.com • E-mail: tech-bds@sporttruckusainc.com

SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park vehicle on clean, flat, and level surface. Set the parking brake.
2. Remove the factory splash shield and factory differential skid plate. Retain all hardware. If factory parts are not installed, hardware must be purchased separately.
3. Bolt the BDS logo onto the splash guard with hardware from #978, the washer goes with the nut on the backside. Do not put a washer on the button head side. Tighten to 18 ft-lbs.
4. Install splash guard and differential skid plate with factory hardware. Tighten to factory specification. Recheck hardware after 500 miles.

Box Kit		
Part #	Qty	Description
02967	1	2011 Chevy HD 3" Diff Skid Plate
02968	1	2011 Chevy HD 3" Splash Shield
02899	1	Large Bolt On Logo
978	1	Bolt Pack
	2	1/4"-20 x 3/4" BHSCS - Stainless Steel
	2	1/4" SAE Washer - Clear Zinc
	2	1/4"-20 Nylock Nut - Clear zinc

