



491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: [www.bds-suspension.com](http://www.bds-suspension.com)

E-mail: [tech@bds-suspension.com](mailto:tech@bds-suspension.com)

Part#: 122312, 122601, 122621

**Product: Track Bar Relocation Bracket**

Application: 2003-2008 Dodge 2500 4wd

---

**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR  
TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

---

## INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the front track bar from the driver's side frame mount. Retain hardware.
3. Install the new track bar bracket in the OE frame mount with the provided 9/16" x 3" bolt on 03-07 models and 5/8" x 3" bolt on '08 models, nut and 1/2" USS washers. Leave hardware loose.
4. Attach the other end of the bracket to the frame crossmember with a 9/16" x 3" bolt, nut and washers through the existing slotted hole. Torque all 9/16" hardware to 125 ft-lbs. and 5/8" hardware to 150 ft-lbs.
5. Install the track bar in the new bracket and secure with the provided 14mm x 80mm bolt, 9/16" SAE washer and OE nut tab for 03-07 models. Use 5/8" x 3" bolt, nut and 5/8" SAE washers on '08 and up. Torque 9/16" hardware to 125 ft-lbs. and 5/8" hardware to 150 ft-lbs. *NOTE: Turn the steering wheel to aid in aligning the track bar in the bracket.*
6. Check all hardware for proper torque.



**Figure**