

# Rear Sway Bar Links

Toyota Tundra | 2007-2019

Part #: 128509 & 128308

Rev. 101819



491 W. Garfield Ave., Coldwater, MI 49036 • Phone: 517-279-2135

Web: [www.bds-suspension.com](http://www.bds-suspension.com) • E-mail: [tech-bds@ridefox.com](mailto:tech-bds@ridefox.com)

## SAFETY WARNING

BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

## INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the OE rear sway bar links from the sway bar and the frame. Save upper and lower hardware and spacer.
3. Locate the new sway bar links. Lightly grease and install the provided hourglass bushings into each end of the links. One of each sleeve sizes will be installed in the sway bar links.
4. Attach the new links to the upper frame mount using the factory hardware and spacer. Leave hardware loose.
5. Attach the lower end of the new sway bar links to the sway bar with the OE sway bar link mounting hardware. Torque the upper and lower sway bar link hardware to 60 ft-lbs.

### 128509 Box Kit

Part #	Qty	Description
911123	2	19in Sway Bar Link
M02016BK	4	Large Hourglass Bushing
93	2	0.750 x 0.134 x 1.575 Rolled Sleeve
54587	2	0.750 x 0.090 x 1.575 Sleeve

### 128308 Box Kit

Part #	Qty	Description
911125	2	16in Sway Bar Link
SB35BK	4	Hourglass Bushing
93	2	0.750 x 0.134 x 1.575 Rolled Sleeve
54587	2	0.750 x 0.090 x 1.575 Sleeve