

Adhesive Recommendations



New Zealand Edition

| Product | Note | General Installations | High Temperature / High Humidity Installations |
|------------------------------------|--|--|--|
| Laminate & Hybrid Floors | Stairs only (Treads, Risers, Nosing) | Bostik – Ultraset SF H.B. Fuller – Max Bond Selleys – Timber Flex | |
| Vinyl Plank Floors | All Constructions/Types | Strongbond 980 Uzin – KE66, KE 2000S | Eco MZ 4 LVT Strongbond 970 Uzin – KR430 |
| Acoustic back Vinyl Plank | Direct Stick Applications V2 Notch Trowel | UZIN / KE2000 TDS | UZIN KE68T TDS |
| Vinyl Sheet Floors | Direct Stick Applications | Godfrey Hirst Vinyl Bond | Eco MZ 4 LVT Strongbond 970 Uzin – KR430 |
| Timber Floors & Timber Stairnosing | Direct stick installations | – Ultraset SF Mapei – Ultrabond S955 Selleys – Timber Flex | |
| Timber Floors | Double Stick / Acoustic Underlay | Please consult Godfrey Hirst for specification details. | |

Notes:

1. Always follow the adhesive manufacturer's directions.
2. High-temperature (HT) installations are those areas where, either geographically or in the build environment, the flooring will be exposed to high and/or large variations in temperature, direct heat, sunlight, humidity or water.
3. Pressure Sensitive Adhesives are not recommended and may void the flooring warranty. Where the installation requires this type of adhesive, seek specialist advice from your adhesive supplier.
4. Specialist installations - such as vinyl plank, vinyl sheet and timber - over an acoustic underlay, require specialist adhesive advice. Contact your adhesive supplier.
5. Use of non-recommended adhesives may void the product warranty. Any warranty claim must be accompanied with proof of adhesive used.