

Adhesive Recommendations



Australian Edition

Product	Ardex	Bostik	Mapei	Maxbond	Nexus	RLA Polymer	Uzin
Carpet Tiles & Planks	AF 271	Fix A320 Tack	Ultrabond Ecotack TX AU <i>Smooth back tiles use roller</i> <i>Cushion backed U1 notch</i>	Maxbond 2009	Nexus 840 Nexus 848 Nexus 970	RLA GHM444 Roberts 656	U 2600
Laminate Stairs Only (Treads, Risers, nosing)		Ultraset 2 in 1 Ultraset HP Ultraset SF	Ultrabond Eco S955 1K	Maxbond TFA	Nexus 590	RLA MS Timber Adhesive RLA 1018 Fast Set Polyurethane	
Vinyl Tiles & Planks Dryback 2.5mm/3mm product V1 notch trowel 4.5mm product V2 notch trowel	AF 171 AF 180 MS	Stix A800 Premium	Ultrabond Eco V4 SP Ultrabond Eco V4 Evolution Ultrabond Eco VS90 Plus <i>For stairs and risers use</i> Mapecontact Plus	Maxbond 2012	Nexus 870 Nexus 880	Roberts R2000 Roberts R200 Roberts R280 HT RLA 265	KE 66 KE 2000S KR 430 KE 68T
Acoustic Back Using V2 Notch Trowel Only		Stix A800 Premium	Ultrabond Eco V4 Evolution	Maxbond 88	Nexus 825	Roberts R2000 Roberts R200 Roberts R280 HT Roberts 656	
Hybrid Stairs Only (Treads, Risers, Nosing)		Ultraset 2 in 1 Ultraset HP Ultraset SF	Ultrabond Eco MS 4 LVT Wall & Floor	Maxbond TFA	Nexus 590		
Engineered Timber Direct Stick		Ultraset 3 in 1 Ultraset 2 in 1 Ultraset SF Ultraset HP	Ultrabond Eco S955 1K	Maxbond TFA	Nexus 590	RLA MS Timber Adhesive X3 SMP All In One Timber Adhesive	Pallman P4 Pallman P7
T&G/In Lock Adhesive		AV XL Plus		Maxbond X-PVA	Nexus 520 Crosslinking PVA	Roberts R6355 Crosslinking PVA	
Accessories <i>Most generic construction adhesives will work.</i>			Ultrabond Eco S955 1K	Maxbond FGL	Nexus Grippa-Fast 200	RLA 1018 Fast Set Polyurethane	

Notes:

1. Always follow the adhesive manufacturers directions.
2. While Godfrey Hirst recommends this selection of manufacturer's adhesives, we do not guarantee the products listed. Godfrey Hirst does not accept liability for products failing to perform with any of these products. It is the responsibility of the adhesive manufacturer and flooring contractor to ensure the products being used are appropriate for use and applied following the manufacturer's recommendations.
3. This list of products and manufacturers may not be complete or current.
4. High-temperature (HT) installations are those areas where, either geographically or in the build environment, the flooring will be exposed to high and/or large variations in temperature, direct heat, sunlight or humidity.
5. Specialist installations - such as vinyl plank, vinyl sheet and timber - over an acoustic underlay, require specialist adhesive advice. Contact your adhesive or acoustic underlay supplier.
6. Any warranty claim must be accompanied with proof of adhesive used.