

# Manual RoofSupport FireWrap

## STEP 1

Install the cable management track along a fire-resistant wall without causing any damage to the wall, preferably using the RoofSupport Fire Wall Bracket.



## STEP 2

Open the RoofSupport FireWrap and place it in the wire tray with the buckles facing down.



## STEP 3

Route the cabling across the fireproof wall and organize it into a neat bundle in the FireWrap.

*Recommendation: Place a maximum of 30 6mm<sup>2</sup> cables per FireWrap, and separate plus and minus cables in separate FireWraps.*



## STEP 4

Close the FireWrap by feeding the straps through buckles and pulling them tight. The barbs in the buckles provide extra grip.

*See detail photo*

