

Comfort Flow mats can be cleaned in several different ways.

- Commercially laundered (see Laundering Instructions)
- Sterilized in an autoclave
- Washed in a commercial dishwasher (please check your local health code for restrictions)
- Washed by hand using the following instructions: Scrub with a deck brush (as needed), using a detergent with a neutral pH. Rinse with a hose or pressure washer. Hang to dry.

Laundering Instructions

Comfort Flow mats can be commercially laundered to remove oil, grease, and soil. The formula below does not require extensive mechanical action or drying; it is designed to dissolve grease residue by using hot water to emulsify oils and grease.

1. Flush 2-3 minutes, high water level, 120 degrees F (49 degrees C)
2. Break 5-10 minutes, high water level, 140 degrees F (60 degrees C)
3. Rinse 2 minutes, high water level, 120 degrees F (49 degrees C)
4. Rinse 2 minutes, high water level, cold
5. Lay mats flat following removal from washer. Allow to cool before rolling.