

Cleaning Instructions

WaterHog Eco Elite Roll Goods mats should be vacuumed regularly (daily in high-traffic areas; weekly in lower-traffic applications). They can also be cleaned with an extractor or hosed off as necessary to remove heavy soil. Hang dry and always make sure they are dry before placing them back in service.

Installation Instructions

Measure

Determine the number of square feet that you will need. Measure the length and width of the area you wish to cover. Multiply the width by the length to get the square footage of the space. For areas that are not rectangular, break the area into smaller rectangles. Multiply the width times the length for each of the smaller rectangles separately and add up all the results to arrive at the overall square footage.

Prepare

Remove any old floor coverings, debris, and adhesives from the floor. Clean the entire floor surface of any dust, drywall mud, etc. Once the floor has been cleaned, allow it to dry completely. Allow the matting material to sit in the area uninstalled for several hours so it can acclimate to room temperature prior to installation.

Install

Apply your adhesive to the prepared floor according to the adhesive manufacturer's directions. We recommend CA024 multi-purpose solvent-free adhesive for all installations, both indoor and outdoor. Never use an adhesive that contains solvents. Like laying carpet, roll the matting out over the installation area and carefully trim the excess material around the perimeter using a utility knife.