

ABS PREMIUM PUMP FIXTURE INSTALLATION INSTRUCTIONS

FOR ENGINEERING

Fixture Installation Instructions

Recommended Mounting Methods:

To be ADA compliant, top of bracket should be 48" from finished floor.

INSTALLATION KIT INCLUDES:
Wall anchors, screws, pre-mounted
3M double-sided adhesive tape strips,
key, and installation template.

"IMPORTANT INFORMATION BEFORE INSTALLING DISPENSER BRACKET SYSTEM"

Please review all operation and installation instructions with your hotel engineering department and tile and shower wall supplier/manufacturer before installing dispenser bracket system.

In no event shall Guest Supply be liable for any damages of any sort arising out of the installation of the dispenser bracket system, whether direct, indirect, special, incidental, consequential or otherwise.

METHOD 1: Mount using ANCHORS and SCREWS.

- **Step 1** - Locate a flat, even surface for mounting bracket, away from a direct continuous stream of shower water.
- **Step 2** - Clean surface with detergent to remove all soap film and dirt.
- **Step 3** - Using a fresh, clean cloth, wipe the surface with a 50/50 mixture of isopropyl alcohol/water and pat dry.
- **Step 4** - Unlock and remove the upper portion from the bracket (page 3, steps 1-2).
- **Step 5** - Using the bracket base as a template, mark the screw hole locations on the wall. Use a level to make sure bracket is properly aligned.
- **Step 6** - If installing more than 1 bracket, use the template for correct spacing between brackets (figures 1 & 2).
- **Step 5** - Drill holes at the marked locations and install the provided anchors.
- **Step 6** - Place the bracket against the wall and secure using the screws provided.
- **Step 7** - After securing, apply a small silicone bead around perimeter of bracket.
- **Step 8** - Allow 24 hours for silicone to cure before bracket assembly and bottle installation.



Fig. 1: If mounting more than 1 bracket, use mounting template for correct bracket spacing.



Fig. 2: If mounting more than 2 brackets, mount additional brackets one-at-a-time using the template as shown.

ABS PREMIUM PUMP FIXTURE INSTALLATION INSTRUCTIONS

FOR ENGINEERING

Fixture Installation Instructions: (CONTINUED)

METHOD 2: Mount using 3M TAPE STRIPS.

- **Step 1** - Locate a flat, even surface for mounting bracket, away from a direct continuous stream of shower water.
- **Step 2** - Clean surface with detergent to remove all soap film and dirt.
- **Step 3** - Using a fresh, clean cloth, wipe the surface with a 50/50 mixture of isopropyl alcohol/water and pat dry.
- **Step 4** - Using a level, locate and mark bracket position.
- **Step 5** - Unlock and remove the upper portion from the bracket (page 3, steps 1-2).
- **Step 6** - Carefully remove the film cover from the adhesive strip on the back of the bracket.
- **Step 7** - Position bracket as marked. **Press firmly (15 pounds-force minimum) for 30 seconds to secure to wall.**
- **Step 8** - If installing more than 1 bracket, use the template for correct spacing between brackets (figures 1 & 2).
- **Step 9** - After brackets are secured, apply small silicone bead around perimeter of each bracket.
- **Step 10** - **Allow 24 hours for adhesive tape & silicone to cure before bracket assembly or bottle installation.**



Fig. 1: If mounting more than 1 bracket, use mounting template for correct bracket spacing.



Fig. 2: If mounting more than 2 brackets, mount additional brackets one-at-a-time using the template as shown.

REMOVING a dispenser installed with 3M ADHESIVE TAPE.

Remove the silicone bead using a plastic caulk scraper. Try gently pulling the dispenser from the wall, do not use excessive force as this may damage the wall. A length of fishing line may be used to cut through the adhesive bond-line. Use liquid soap as a lubricant.

Alternatively, 2 soft plastic putty knives can be used to gently pry the edge away from the wall, slowly working your way around the perimeter of the dispenser. If the bond is particularly strong, heating the dispenser with a hair dryer will soften the adhesive.

Use a solvent to remove any remaining adhesive residue from the wall. Be sure the solvent is approved by the manufacturer of the wall substrate and will not cause damage to the wall.

ABS PREMIUM PUMP FIXTURE OPERATION INSTRUCTIONS

FOR HOUSEKEEPING Bottle Installation & Replacement:

DO NOT USE abrasive cleaning chemicals, abrasive acidic cleaning chemicals or abrasive cleaning sponge or cloth.

IMPORTANT

WAIT AT LEAST 24 HOURS after bracket installation before installing bottles.

Bracket Operation



STEP 1
Locate the keyhole on the underside of the bracket, below the bottle.



STEP 5
Slide the top bracket and bottle onto the fixture.



STEP 2
Slide the key into the keyhole and press UPWARD firmly to UNLOCK.



STEP 6
Press downward on the top bracket until it clicks. The bracket locks automatically.



STEP 3
With the key inserted, remove the bottle and top bracket together by lifting straight up.



STEP 7
Open the bottle pump by turning the spout COUNTERCLOCKWISE until it pops up.



STEP 4
Separate the bottle from the top bracket, and replace the bottle.



STEP 8
Remember to save the key in a secure location for future use.

ABS PREMIUM PUMP FIXTURE CARE INSTRUCTIONS

These guest room accessories are handcrafted and require special care for long term enjoyment.

CAUTION: DO NOT USE

Bleach

Abrasive cleaning chemicals

Acidic cleaning chemicals

Abrasive cleaning sponge / cloth

RECOMMENDED CLEANING INSTRUCTIONS



Use clean damp cloth with mild soap to gently wipe down the bracket, bottles & pump spouts.



Wipe with clean damp cloth to remove soap.



With a dry clean cloth, wipe off all cleaned areas to remove water spots.

Warranty available upon request.