# **SIMPLIFIED Iron Installation with...**

With IronPro accessories, you can enjoy a beautiful Before iron balustrade installed in 1/3 of the time of a typical installation. The combination of wood handrail, wood newels and iron balusters will match most any décor and can add value to your home. IronPro is secured

to the handrail, treads and kneewall utilizing high quality, self-drilling screws or bolts. It's ideal for remodeling too!



#### View IronPro Video...

for your phone



# **Finished Look:**

Open Tread Top Connection









# **Elégant Look**

**Full Flexibility** 

• Unique and sophisticated attachment hardware

• Adjusts to up to 45° angle of ascent • Open Tread and Kneewall Stairways

• Balusters are screwed into place

**Unsurpassed Durability** 



**Bottom Connection** 



Bottom Connection



# The installation process is fast & simple...

Cut the wood baluster and remove. (For remodel only)



Attach the IronPro Fasteners using the provided hardware.



Measure and cut the iron balusters.



Insert the iron baluster. pivot, and swing into



Align the assembly and screw into place. Tighten



Detailed instructions are available at www.LJSmith.com

Important: When replacing wood balusters with iron balusters, be sure to check your local building codes for compliance. For Interior Use Only.

# **What does your** stairway look like?



**Open Tread** 



Kneewall

Now you can begin selecting *Fron* Pro™ components for your stairway.

# **How to Select IronPro™ Components...**

**IronPro™** is for use with 1/2" iron balusters

### Open Tread Stairway

Select one Fron Pro<sup>TM</sup> Level Kit (LI-PROLVL) for each baluster you plan to install. This kit includes the items to the right.









Centering





# Kneewall Stairway

Select one Fron Pro™ Kneewall Kit (LI-PROKNE) for each baluster you plan to install. This kit includes the items to the right.





### Level Sections (if applicable)

Select one Fron Pro™ Level Kit for each baluster you plan to install on level sections. This is the same packet as is used for an Open Tread Stairway (above). A **Kneewall Kit** can be used on level sections, if preferred.

# Optional Products Available . . .

**Used when replacing wood** balusters with IronPro™

Universal Cover Plate

Select one metal Universal Cover Plate (LI-PROPLT1) for each 11/4" or 13/4" wood baluster replacement on open treads or level sections when using the Base Collar & Threaded Disc, or on a kneewall when using the Round Socket.



Select one metal **Rectangular Socket Cover Plate** (LI-PROPLT2) for each 11/4" or

134" wood baluster replacement on a kneewall when using the rectangular socket.



© 2012 L.J. Smith, Inc.

#### Fillet - Used when the spacing of the balusters change in the handrail or shoerail



will change.

LJ-6000F Fillet for 11/4" plowed handrail and/or shoerail.

LJ-6007 Fillet for 13/4"

Fillet is also used under non-plowed

rail when the spacing of the balusters

plowed handrail and/or shoerail.



For detailed instructions, visit www.LJSmith.com



L.J. Smith Stair Systems

35280 Scio-Bowerston Road • Bowerston, OH 44695 (740) 269-2221 • Fax (740) 269-9047

Form No: LJ-0112 IRONPRO





Patent Pending

**Level Kit** 













#### **GREEN BAY, WI**

551 Packerland Dr.

1-920-499-2117

Email:

woolfgb@woolfdistributing.com Orders:

order-gb@woolfdistributing.com

## PEORIA, IL

515 South Maxwell Rd.

1-309-697-1760

Email:

woolfpe@woolfdistributing.com Orders:

order-pe@woolfdistributing.com

## WOODSTOCK, IL

1625 West Lake Shore Dr.

woolf-ws@woolfdistributing.com

Building Materials: 1-815-477-9680

order-ws@woolfdistributing.com

Millwork: 1-815-356-0438

order-mw@woolfdistributing.com

Commercial: 1-815-527-9288

commercialdoors@woolfdistributing.com