

**HBF** Hickory, NC 28601  
828-328-2064

## ASSEMBLY INSTRUCTIONS

### POWER INFEED CABLE / WIRE CLIP / LEG ASSEMBLY INSTRUCTIONS

#### GENERAL NOTES

- 1.) REPORT DAMAGE BEFORE PROCEEDING.
- 2.) ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
- 3.) ALWAYS LEVEL UNIT AT FINAL LOCATION
- 4.) THESE INSTRUCTIONS ARE FOR A COSTA TABLE LEG IN WHICH A POWER INFEED CABLE IS BEING INSTALLED ONLY.

## ATTACH WIRE CLIP TO LEG

STEP 1) REMOVED COVER ON LEG IN WHICH POWER INFEED CABLE IS TO BE INSTALLED.

STEP 2) SECURE CABLE IN PLACE USING WIRE CLIP (P/N: A1907-3002-24) INTO .25" DIA HOLES AT THE TOP AND BOTTOM OF THE LEG POST. MAKE SURE CLIP IS SEATED FULLY INTO THE .25" DIA HOLES AND WILL NOT POP OUT.



P/N: A1907-3002-24



WRAP THE WIRE CLIP AROUND THE CONDUIT BEFORE INSERTING INTO THE POST

## RE-ATTACH LEG COVER

STEP 3) RE-ATTACH LEG COVER (SHOW WITH HARD-WIRED CABLE VERSION).

